# IMPORTANT SAFETY INSTRUCTIONS

When using your travel adapter plug, basic precautions should always be followed, including the following:

## 1. READ ALL INSTRUCTIONS BEFORE USING.

- 2. DO NOT use this adapter plug with products containing screwbase lampholders (sockets) or convenience receptacles.
- 3. THIS PRODUCT IS NOT A VOLTAGE **CONVERTER.** Check the rating on each appliance and use this adapter plug only with appliances rated for both 120 and 240 volts. Use with appliances rated only 120 volts may result in a risk of fire, electric shock, injury to persons, or damage to the appliance. For use in countries overseas, the voltage selector on your dual-voltage appliance may need to be placed in the 240volt position. Confirm the voltage available at each overseas location before using this adapter plug with an appliance.
- 4. Be sure the dual-voltage selector switch, when provided with your appliance, is in the correct voltage position before operating. Before plugging in,

read the information about dualvoltage operation contained in these instructions and in the instructions provided with each appliance to be used with this adapter plug.

- 5. Always attach the adapter plug to the plug of the appliance first. then insert the adapter plug into the outlet.
- 6. Always disconnect the adapter plug and the appliance from the electrical outlet when not in use.

ELECTRICAL RATING: AC portion: 8A MAX. 100-240VAC USB portion: 5V DC, 2.1A MAX

# SAVE THESE INSTRUCTIONS

#### TO SELECT PROPER PLUG

UK - Push the button on the right side all the way down to where "UK" is indicated. Then, bring down the middle prong from the bottom of the unit.

**Europe** - Push the button to the middle position where "Europe" is indicated. Press button to release plug.

North America/South America/Japan Push the button all the way up to where "USA/AUST" is indicated. Prongs will be straight up and down.

Australia/New Zealand - Push the button all the way up to where "USA/AUST" is indicated. Swivel each prong to the proper angle (as shown).

Note: When using a 2- or 3-prong Australia/New Zealand appliance. you may need to apply some force to the plug to insert it all the way. When the unit is plugged in and the indicator light is on, both the AC & USB portions are functioning properly. But if the indicator light is off, the AC portion can still be used, but the USB portion charger function is defective and can't be used

USB port - Be sure your product uses USB for charging or damage may occur (some cameras that include a USB cable are data transfer only, not for charging)

## CAUTION

This product does not convert electrical voltage. You will need a converter or transformer for your single-voltage appliances.

Important - Indoor use only!

This Class (B) digital apparatus complies with Canadian ICES-003.



USB Port



Great Britain. Ireland, Africa, Hong Kong. and Singapore



Europe, Middle East, parts of Africa, Asia, South America. and the Caribbean



North and South America. Caribbean, Japan, and parts of China



Australia, Fiii. New 7ealand. and parts of China

# LIMITED TWO-YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty. return the defective product to the service centre listed below, together with your purchase receipt and \$7.50 for postage and handling. In the absence of a purchase receipt, the warranty period shall be 24 months from the date of manufacture.

IMPLIED WARRANTIES. OBLIGATIONS. OR LIABILITIES. INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SHALL BE LIMITED IN DURATION TO THE 24 MONTH DURATION OF THIS WRITTEN. LIMITED WARRANTY.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL INCIDENTAL, OR CON-SEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED. WHATSOEVER.

This warranty gives you specific legal rights, and you may also have other rights, which vary from province to province.

Service Centre/ Service après-vente Conair Consumer Products Inc.

100 Conair Parkway, Woodbridge, ON L4H 0L2

Travel Smart® is a trademark of Conair Consumer Products Inc. Travel Smart® est une marque de

commerce de

Conair Consumer Products Inc. Customer Service:

1-800-472-7606 Service à la clientèle:

1-800-472-7606

# www.travel-smart.ca

Travel Smart®, a division of Conair Consumer Products Inc. Travel Smart® est une filiale de Conair Consumer Products Inc. 100 Conair Parkway, Woodbridge, ON L4H 0L2 ©2012 Conair Consumer Products Inc.

IB-17809

12CN136195

•:• LectronicSmart

All-in-One Adapter with built-in USB port Adaptateur tout-en-un avec port USB intégré

> Have a Ouestion? Please do not return this product to the retailer. **Call Us First!**

Our customer service and product experts are ready to answer ALL vour questions

Please call our TOLL-FREE custome service number at: 1-800-472-7606 or visit us online at www.conaircanada.ca

Des questions?

Veuillez ne pas retourner ce produit au détaillant.

Appelez-nous d'abord! Notre Service à la clientèle et nos

experts sont prêts à répondre à TOUTES vos questions. Veuillez com-poser le NUMERO SANS FRAIS de notre Service à la clientèle : 1-800-472-7606 Ou visitez notre site Internet au www.conaircanada.ca

Instruction Guide • Directives

# **IMPORTANTES** CONSIGNES

L'utilisation d'adaptateurs de prises requiert la prise de précautions élémentaires, dont les suivantes :

## 1. LIRE TOUTES LES INSTRUCTIONS AVANT D'UTILISER L'APPAREIL.

- 2. NE PAS utiliser cet adaptateur de prises pour brancher des appareils munis de douilles ou de prises à vis.
- 3. CE PRODUIT N'EST PAS UN CONVERTISSEUR DE TENSION.

S'assurer que l'appareil avec lequel il est utilisé est bitension (120/240V). Utiliser un adaptateur de prise avec un appareil à tension unique (120V) peut présenter un risque d'incendie. d'électrocution et de blessure, ou peut endommager l'appareil. Pour utiliser votre appareil dans un pays dont le courant est de 220-240V. mettre le sélecteur de tension de l'appareil à "240". Vérifier la tension avant de brancher l'appareil.

- 4. Si votre appareil bitension est muni d'un sélecteur de tension. veiller à ce que ce dernier soit à la bonne position avant de brancher l'appareil. Avant de brancher l'appareil, lire les instructions avant trait à la bitension contenues dans ce livret et dans le mode d'emploi de l'appareil.
- 5. Connecter l'appareil à l'adaptateur avant de le brancher sur la prise de courant.
- 6. Débrancher l'adaptateur lorsque vous ne l'utilisez pas.

SPÉCIFICATIONS ÉLECTRIQUES: Prise CA: 8A MAX. 100-240V CA Port USB: 5V CC. 2.1A MAX

# **GARDER CES INSTRUCTIONS**

### CONFIGURATION DES PRISES

Royaume-Uni - Régler le sélecteur de tension à « UK ». Abaisser la fiche du milieu.

**Europe -** Régler le sélecteur de tension à « Europe ». Appuver sur le bouton pour libérer les fiches rondes.

Amérique du Nord/Amérique du Sud/Japon - Régler le sélecteur de tension à « USA/AUST ». Les

fiches plates sortiront. Australie/Nouvelle-Zélande - Régler le sélecteur de tension à « USA/AUST ». Positionner les broches en V inverse. comme ci-contre.

Remarque: Les prises des appareils australiens/nouveaux-zélandais s'enfonceront dans l'adaptateur avec un peu de difficulté. Il faudra un peu forcer. Le témoin lumineux devrait être allumé lorsque l'appareil est branché. Si le témoin lumineux ne s'allume pas lorsque l'adaptateur est branché, cela signifie que seule la connexion secteur fonctionne et que la connexion USB n'est pas opérationnelle.

Port USB - Pour éviter les risques de dommages, s'assurer que l'appareil est rechargeable par l'intermédiaire du port USB (le câble USB de certains appareils photos sert au transfert de données, et non au chargement).

#### AVERTISSEMENT

Ce produit ne convertit pas la tension. À moins que votre appareil ne soit bitension, il vous faudra utiliser un convertisseur ou un transformateur en complément de l'adaptateur de prise.

Important – Ne pas utiliser à l'extérieur!

Cet appareil numérique de la classe (B) est conforme à la norme NMB-003 du Canada.



Angleterre, Irlande, Afrique, Hong Kong et Singapour



T

Europe, Moyen Orient, certaines régions d'Afrique. Amérique du Sud. Asie et Antilles



et régions de la Chine

et régions de



la Chine Australie, îles Fidii. Nouvelle-7élande



Conair, à son choix, réparera ou remplacera le produit sans frais au cours des 24 mois suivant la date d'achat, si le produit présente un vice de matériau ou de fabrication.

Pour obtenir un service au titre de la garantie, retournez le produit défectueux au service après-vente indiquée ci-dessous. accompagné du reçu d'achat et de 7,50 \$ pour les frais de poste et administratifs À défaut de présenter un reçu d'achat, la période de garantie sera de 24 mois à compter de la date de fabrication.

GARANTIE IMPLICITE OBLIGATION OU RESPONSABILITÉ. Y COMPRIS MAIS SANS Y ÊTRE LIMITÉ LA GARANTIE IMPLICITE DE QUALITÉ MARCHANDE OU D'ADAPTATION À UN USAGE PARTICULIER, SERA LIMITÉE À LA DURÉE DE 24 MOIS DE CETTE GARANTIE LIMITÉE ÉCRITE.

EN AUCUN CAS PEUT-ON TENIR CONAIR RESPONSABLE DE QUELQUE DOMMAGE SPÉCIAL. INDIRECT OU FORTUIT QUE CE SOIT POUR L'INEXÉCUTION DE LA PRÉSENTE GARANTIE OU DE TOUTE AUTRE GARANTIE. EXPRESSE OU IMPLICITE QUE CE SOIT.

Cette garantie vous accorde des droits légaux particuliers et peut vous accorder d'autres droits qui varient d'une province à l'autre.